

Pedal Adapter Instructions



1. Place bolts through top adapter piece, determining appropriate bolt placement based on pedal size and shape. Optimal placement is for the ball of the foot over the pedal.

2. Place bottom piece face up on the floor, placing locking nuts over the holes that match up with your choice of bolt placement



3. The locking nuts are press fit, they are a tight fit. Start pressing them in from the top, then carefully flip piece over and push firmly to slide the nuts all the way in.

4. Nuts should press in far enough to be flat with the top.



5. Place the top piece back over the pedal aligned with your bolt placement.



6. Flip pedal over with top piece of adapter on



7. Place bottom piece of adapter on top, nuts should line up with bolts



8. squeeze piece together and flip adapter over



9. Use one hand to hold the adapter together and other hand to tighten bolts and secure top and bottom together. Tighten each bolt a little at a time to achieve equal tightness and equal spacing between top and bottom pieces.





nerdydoodle.com